

Cleaning acrylic and polycarbonate sheets or display cover glass

What to use:

- Synthetic microfiber wipes without any added chemicals.
- IPA/H₂O* mixture as described below.
- Clean and dry hands – we recommend using powder-free and disposable silicone rubber or PUR gloves.

How to use:

- Moisturize the wipe lightly (spray once or twice only).
- Clean the surface by wiping from the center towards the edges (wet wiping).
- Use a dry wipe for final polishing immediately after wet wiping.
- Apply circular motions from the center and outwards. This should remove remaining stripes or stains completely.
- Repeat wet wiping and dry polish if the cleaning has failed to remove contaminants.

Please note:

- Do not wash (recycle) wipes using softeners or detergents.
- Do not polish the surface using abrasive materials (glass/ceramic cleaner).
- Do not use regular 'kitchen wipes', as they might produce scratches.
- Non-woven polishing wipes similar to Katrin 45591 (www.katrin.com or ABSORMAT™ (www.crtoy.com), is also recommended.
- Do NOT apply any substances that claim to improve surface quality i.e., silicon sprays and 'lotus effect sprays'.

*IPA (Isopropanol) and distilled water mixtures in ratios between 30/70% and 70/30%.